



Husqvarna Xcite Z375 Zero Turn Lawn Mower User Manual

[Home](#) » [Husqvarna](#) » [Husqvarna Xcite Z375 Zero Turn Lawn Mower User Manual](#) 

Contents

- [1 Husqvarna Xcite Z375 Zero Turn Lawn Mower](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Conformity certificates](#)
- [5 Introduction](#)
- [6 Product overview](#)
- [7 Safety](#)
- [8 Operation](#)
- [9 To engage and disengage the parking brake](#)
- [10 Maintenance](#)
- [11 To clean the product](#)
- [12 Troubleshooting](#)
- [13 Transportation, storage and disposal](#)
- [14 Technical data](#)
- [15 Battery charging times](#)
- [16 Electrical diagram](#)
- [17 SUGGESTED GUIDE FOR SIGHTING SLOPES FOR SAFE OPERATION](#)
- [18 Documents / Resources](#)
 - [18.1 References](#)
- [19 Related Posts](#)



Husqvarna Xcite Z375 Zero Turn Lawn Mower



Product Information

Specifications

- **Product Name:** Xcite™ Z375
- **Language:** English
- **Operator's manual:** Included
- **Product Numbers:**
 - **Product Number:** [Product Number]
 - **Serial Number:** [Serial Number]
 - **Engine:** [Engine Model]
 - **Transmission:** [Transmission Model]
- **Product Overview:**
 - Accessory rack
 - Fuel tank
 - Seat suspension adjustment
 - Cutting height adjustment
 - Left control lever
 - Tracking control
 - Fuses
 - Parking brake pedal
 - Battery compartment cover
 - Seat adjustment lever
 - Deck lifting pedal
 - Right control lever
 - Fuel gauge
 - Hourmeter
 - Ignition switch
 - PTO button

- Type plate
- Throttle control
- Oil drain plug
- **Safety Symbols:**
 - **WARNING:** This product can be dangerous and cause serious injury or death to the operator or others. Be careful and use the product correctly.
 - Read the operator's manual carefully and make sure that you understand the instructions before you use the product.
 - Stop the engine and remove the key before you do maintenance.
 - Keep a safe distance from the product.
 - Do not park the product on slopes.
 - Do not keep passengers. Look out for ejecting objects and ricochets
 - Keep hands and feet away from the cutting deck.
 - Keep hands away from rotating parts.

Product Usage Instructions

Introduction

- A pre-delivery inspection has been done of this product. Make sure that you receive a signed copy of the pre-delivery inspection document from your dealer.
- **Service agent contact information:** This operator's manual is for product with product number
- **serial number:** [Product Number]
- **Engine:** [Engine Model]
- **Transmission:** [Transmission Model]
- The product numbers are found on the type plate.
- Refer to [Product overview](#) for the location of the type plate.


• **Product Description**

This product is a ride-on lawn mower. The control levers let the operator steer the product and adjust the speed of the product. An hour meter shows how many hours the product has been used.

• **Intended Use**

- The product is made to cut grass on open and level ground only.
- Do not use the product for other tasks.

Product Overview



- **Troubleshooting**

If you encounter any issues with the product, refer to the Troubleshooting section in the user manual for possible solutions.

- **Maintenance**

Regular maintenance is important to keep the product in good working condition. Refer to the Maintenance section in the user manual for detailed instructions on how to maintain the product.

- **Transportation, Storage, and Disposal**

When transporting, storing, or disposing of the product, follow the guidelines provided in the user manual to ensure safety and proper handling.

- **Technical Data**

For detailed technical specifications of the product, refer to the Technical Data section in the user manual.

- **Service**

If you require service or repairs for the product, contact a service agent. The contact information can be found in the user manual.

- **Appendix**

Refer to the Appendix section in the user manual for additional information and resources related to the product.

FAQ

1. **Q: Can I use the product on slopes?**

A: No, the product is not designed to be used on slopes. It is intended for use on open and level ground only.

2. **Q: What should I do if I encounter any issues with the product?**

A: Refer to the Troubleshooting section in the user manual for possible solutions. If the issue persists, contact a service agent for further assistance.

3. **Q: How often should I perform maintenance on the product?**

A: Regular maintenance is important to keep the product in good working condition. Follow the maintenance schedule provided in the user manual for guidance on when to perform specific maintenance tasks.

4. **Q: Where can I find the product numbers?**

A: The product numbers can be found on the type plate. Refer to the Product Overview section in the user manual for the location of the type plate.

Conformity certificates

- **USA requirements**

- Labels are placed on the engine and/or in the engine compartment stating that the machine will fulfill the requirements. Do not remove these labels. Certificates can also be supplied with the machine at delivery or written in the Engine manual. Take care of them as they are valuable documents.
- To implement improvements, specifications and designs can be altered without prior notification.

Introduction

- **Pre-delivery inspection and product numbers**

A pre-delivery inspection has been done of this product. Make sure that you receive a signed copy of the pre-delivery inspection document from your dealer.

Service agent contact information:	
This operator's manual is for product with product number / serial number:	
/	
Engine:	
Transmission:	

The product numbers are found on the type plate. Refer to Product overview on page 3 for the location of the type plate.


- **Product description**

- This product is a ride-on lawn mower. The control levers let the operator steer the product and adjust the speed of the product. An hour meter shows how many hours the product has been used.

- **Intended use**

- The product is made to cut grass on open and level ground only. Do not use the product for other tasks.

Product overview



1. Accessory rack
2. Fuel tank
3. Seat suspension adjustment
4. Cutting height adjustment
5. Left control lever
6. Tracking control
7. Fuses
8. Parking brake pedal
9. Battery compartment cover
10. Seat adjustment lever
11. Deck lifting pedal
12. Right control lever
13. Fuel gauge
14. Hourmeter
15. Ignition switch
16. PTO button
17. Type plate
18. Throttle control
19. Oil drain plug

Symbols on the product

WARNING: This product can be dangerous and cause serious injury or death to the operator or others. Be careful and use the product correctly.



Read the operator's manual carefully and make sure that you understand the instructions before you use the product.



Do not put your foot here.



Stop the engine and remove the key before you do maintenance.



Control levers out.




Keep a safe distance from the product.



Parking brake.



Do not operate the product on slopes larger than 10°.



Cutting deck lift.



Do not park the product on slopes.



Engine speed – fast.



Do not keep passengers.



Engine speed – slow.



Look out for ejecting objects and ricochets.



Neutral.



Keep hands and feet away from the cutting deck.



Reverse.



Keep hands away from rotating parts.



Fuel.



Look out for persons and animals when you operate the product forward.



Do not operate the product without deflector or grass catcher.



Look out for persons and animals when you operate the product rearward.



Low cutting height.



Do not sit on the accessory rack.



High cutting height.



Headlights.



Push PTO button.



Start engine.



Warning! Battery acid is corrosive, explosive and flammable.



Keep body parts away from rotating parts.


yyyywwxxxx

The rating plate shows the serial number. **yyyy** is the production year and **ww** is the production week.

Note: Other symbols/decals on the product refer to certification requirements for some commercial areas.

Steering controls

- The direction of the product is controlled by the 2 control levers.
- The control levers must be moved out to the park position (A) to start the product. The control levers can be moved forward and rearward from the neutral position (B). Refer to To operate the product for the first time on page 11.




• Operator Presence Control (OPC)


The OPC engages when the operator lifts from the seat. The engine and the drive to the blades stop if the blades are engaged or the parking brake is not applied. Refer to Operation conditions on page 9.

Ignition key

- The ignition key has 4 positions:
 - Start position (A)
 - Run position (B)
 - Headlight position (C)
 - Stop position (D)



Headlights




- Turn the ignition key to the headlight position (C) to operate the product with the headlights on.
- Turn the ignition key to the run position (B) to operate the product with the headlights off.


PTO (Power Take-Off) button

The PTO button engages and disengages the PTO clutch and the cutting deck or other equipment connected to it. The correct start conditions must be obeyed to engage the drive of the blades. Refer to Operation conditions on page 9 for the correct start conditions.

- Pull the PTO button out to engage the drive to the blades or other equipment.




- Push the PTO button in to disengage the drive to the blades or other equipment.



- **Hour meter**


The product has an hour meter that show how many hours of operation that the blades have been engaged. Refer to Product overview on page 3 for the position of the hour meter.



- Each 50 hours an oil level symbol will show for 2 hours. Refer to To do a check of the engine oil level on page 21.

- **Throttle control**

The throttle control adjusts the speed of the engine and the speed of the blades if the blades are engaged. The throttle control has 2 end positions, idle speed and full throttle.



- Idle speed (A) – decreases the engine speed.
- Full throttle (B) – increases the engine speed.
- **CAUTION:** Do not operate the engine at idle speed (A) for longer time than necessary. Too much operation time at idle speed can decrease the life of the spark plugs.

Fuses

- The location of the fuses is in the fuse box. The fuse box is below the seat. Remove the battery compartment

cover to get access to the fuse box. Refer to the decal on the fuse box for identification of the different fuses.

- **Product damage**

- We are not responsible for damages to our product if:
- the product is incorrectly repaired.
- the product is repaired with parts that are not from the manufacturer or not approved by the manufacturer.
- the product has an accessory that is not from the manufacturer or not approved by the manufacturer.
- the product is not repaired at an approved service center or by an approved authority.

Safety

- Safety definitions

Warnings, cautions and notes are used to point out specially important parts of the manual.

- **WARNING:** Used if there is a risk of injury or death for the operator or bystanders if the instructions in the manual are not obeyed.
- **CAUTION:** Used if there is a risk of damage to the product, other materials or the adjacent area if the instructions in the manual are not obeyed.
- **Note:** Used to give more information that is necessary in a given situation.

General safety instructions

- **WARNING:** Read the warning instructions that follow before you use the product
- **WARNING:** Failure to follow cautious operating practices can result in dangerous injury to the operator or other persons. The owner must understand these instructions, and must let only approved persons who understand these instructions to operate the mower. Each person operating the mower must be of sound mind and body and must not be under the influence of mind altering substances.
- **WARNING:** This product is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury or death.
- Read, understand, and follow instructions and warnings in this document, the operator's manual and on the product, engine and attachments.
- Only allow operators, who are responsible, trained, familiar with the instructions, and physically capable to operate the product.
- Make sure to inform a person that you are going to operate the product if an injury or accident occurs.
- Do not carry passengers and keep bystanders away.
- Do not operate the product while under the influence of alcohol or drugs.
- Follow the manufacturer's recommendation for wheel weights or counterweights.
- Learn how to use the product and its controls safely and learn how to stop the product quickly.
- Learn to recognize the safety decals.
- Keep the product clean to make sure that you can clearly read signs and stickers.
- Keep in mind that the operator will be held responsible for accidents that involve other persons or their property.
- Only use the product in daylight or in other well-lit conditions. Keep the product at a safe distance from holes or other irregularities in the ground. Look out for other possible risks.
- Do not let children or other persons not approved for operation of the product to use or do servicing on it. Local laws may regulate the age of the user.
- Make sure that nobody else is in the vicinity of the product when you start the engine, engage the drive or start

to move the product.

- Keep an eye on the traffic when you mow near a road or move across a road.
- Do not use the product if you are fatigued, while under the influence of alcohol or drugs, medicine or anything that can have a negative effect on your vision, alertness, coordination or judgement.
- Always park the product on a level surface with the engine stopped.
- Do not make modifications to this product.
- Do not operate the product if it is possible that other persons have made modifications to the product.

Safety instructions regarding children

- **WARNING:** Children can be seriously injured or killed by this product. Read the warning instructions that follow before you use the product. Keep children away.
- Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the product and the mowing activity. Never assume that children will remain where you last saw them.
- Keep children out of the operating area and under the watchful care of a responsible adult other than the operator.
- Keep an eye out and stop the product immediately, if children enter the work area. Be very careful near corners, bushes, trees or other objects that prevents a clear view.
- Use extreme care when going near blind corners, shrubs, trees, or other objects that can block your view of a child.
- Before and while you move the product in reverse, look behind you and look down for small children.
- Do not let children operate the product.
- The American Academy of Pediatrics recommends that children be a minimum of 16 years of age before operating a riding lawn mower.
- Do not carry children, even with the blade(s) shut off. Children could fall off and be seriously injured or interfere with safe product operation. Children who have been given rides in the past could suddenly appear in the mowing area for another ride and be run over or backed over by the product.

Safety instructions for operation

- **WARNING:** Read the warning instructions that follow before you use the product.
- **WARNING:** Do not touch the engine or exhaust system during or directly after operation. The engine and the exhaust system become very hot during operation. Risk of burn injuries, fire and damage to property or adjacent areas. When you operate the product, keep away from bushes and other objects.
- Only operate the engine in well ventilated areas. Exhaust gases contain carbon monoxide, a deadly poison.
- Only operate the product in daylight or good artificial light.
- Clear the area of objects such as stones, toys, wires, etc. that may become caught in the blades and be thrown out.
- Avoid holes, ruts, bumps, rocks, or other hidden hazards. Uneven terrain could overturn the product, or cause operator to lose their balance or footing.
- Do not put hands or feet near rotating parts or under the product. Keep clear of the discharge opening at all times.
- Do not operate the product without the full grass catcher, discharge guard, or other safety devices in place and working.

- Do not direct discharge material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back toward the operator. Stop the blade(s) when crossing gravel surfaces.
- Do not leave a running product unattended. Always park on level ground, disengage the attachment, set parking brake, and stop engine/motor.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Decrease speed before turning.
- Decrease the speed before you turn around a corner.
- Data shows that operators age 60 years and above are involved in a large percentage of riding mower-related injuries. These operators must evaluate if they can safely operate the riding mower sufficiently to protect themselves and others from injury.

Safety instructions for operation on slopes

WARNING: Read the warning instructions that follow before you use the product.

Slopes are a major factor related to accidents. Operation on slopes requires extra caution.


- Travel in the manufacturer recommended direction on slopes. Use caution while operating near drop-offs.
- Avoid mowing wet grass. The tires can lose traction.
- Do not operate product under any condition where traction, steering, or stability is in question. Tires could slide even if the wheels are stopped.
- Always keep the product in gear when going down slopes. Do not coast downhill.
- Avoid starting and stopping on slopes. Avoid making sudden changes in speed or direction. Make turns slowly and gradually.
- If the tires lose traction, disengage the blades and continue slowly straight down the slope.
- Use extra care while operating product with a grass catcher or other attachment(s). They can affect the stability of the product.
- To cut grass on slopes increases the risk that you can not control the product and that it overturns. This can cause injury or death. It is necessary to cut the grass carefully on all slopes. If you cannot reverse up a slope or if you do not feel safe, do not cut it.
- Remove stones, branches and other obstacles.
- Cut the grass on the slope up and down, not from side to side.
- Do not operate the product on ground that slopes more than 10°.
- Move smoothly and slowly on slopes.
- Look out for and do not move across furrows, holes and bumps. There is a higher risk that the product overturns on ground that is not flat. Long grass can hide obstacles.
- Do not cut grass near edges, ditches or banks. Keep at least the width of the machine away from these hazards. The product can suddenly overturn if a wheel moves across the edge of a steep slope or a ditch, or if an edge gives way.

Personal protective equipment

- **WARNING:** Read the warning instructions that follow before you use the product.
- Use approved personal protective equipment when you use the product. Personal protective equipment cannot fully prevent injury but it decreases the degree of injury if an accident does occur. Let your dealer help you

select the right equipment.

- Always wear approved hearing protection. Long term exposure to noise can result in permanent hearing impairment.
- Always wear safety glasses or eye protection while you operate the product or do maintenance or repairs.
- Always wear protective shoes or protective boots. Steel toes are recommended. Do not use the product barefoot.




- Wear gloves when necessary, for example when you attach, examine or clean the cutting equipment.
- Do not wear loose-fitting clothing, jewelry or other items that can get caught in moving parts.
- Do not wear shorts when you operate the product.
- Keep first aid equipment and fire extinguisher close at hand

Safety devices on the product

- **WARNING:** Read the warning instructions that follow before you use the product.
- Do not use a product with safety devices that are damaged or do not operate correctly. Do a check of the safety devices regularly. If the safety devices are damaged, speak to your Husqvarna service agent.
- Do not make modifications on safety devices. Do not use the product if protective plates, protective covers, safety switches or other protective devices are not attached or are damaged.

To do a check of the ignition key

- Start and stop the engine to do a check of the ignition key. Refer to To start the engine on page 14 and To stop the engine on page 15.
- Make sure that the engine starts when you turn the ignition key to start position.
- Make sure that the engine stops immediately when you turn the ignition key to stop position.
- Accessory rack
- The accessory rack is used for storage and transportation. The weight limit is 30 lb (13.6 kg).
- **CAUTION:**
- For transportation of liquids, use containers that are correctly sealed and not damaged to prevent spills on the engine.
- Attach items to the accessory rack with straps.
- **WARNING:** Do not use the accessory rack as a seat.



Operation conditions

These conditions are necessary to start the engine:

- The control levers are in the park position.
- The parking brake is applied.
- The drive of the blades is disengaged.

The engine must stop in these situations:

- The parking brake is not applied and the operator lifts from the seat.
- The drive of the blades is engaged and the operator lifts from the seat.
- Try to start the engine without 1 of the conditions. Change the conditions and try again. Do this check daily.

Parking brake

- **WARNING:** If the parking brake does not work, the product can start to move and cause injury or damage. Make sure that the parking brake is regularly examined and adjusted.
- Refer to To do a check of the parking brake on page 18.

Muffler

- **WARNING:** Do not use the product if the muffler is missing or damaged. A muffler that is damaged or missing increases the noise level and the risk of fire.
- The muffler keeps the noise levels to a minimum and sends the exhaust fumes away from the operator.
- Examine the muffler regularly to make sure that it is attached correctly and not damaged.
- **WARNING:** The muffler becomes very hot during and after use and when the engine operates at idle speed. Be careful near flammable materials and/or fumes to prevent fire.
- To do a check of the muffler
- Examine the muffler regularly to make sure that it is attached correctly and not damaged.

Spark arrestor

- This product has an internal-combustion engine. Do not use the product near vegetation without a spark arrestor that is approved by local or state laws. Federal laws apply on federal lands.
- A spark arrestor for the muffler is available through your approved Husqvarna dealer.

- **Protective covers**

Missing or damaged protective covers increase the risk of injury on moving parts and hot surfaces. Do a check of the protective covers before you operate the product. Make sure that the protective covers are correctly attached and do not have cracks or other damages. Replace damaged covers.

Fuel safety

- **WARNING:** Read the warning instructions that follow before you use the product.
- **WARNING:** Be careful with fuel. It is very flammable, and can cause injury and damage to property.
- Extinguish all cigarettes, cigars, pipes and other sources of ignition.
- Use only an approved fuel container.
- Do not remove fuel cap or add fuel with the
- Do not refuel indoors or in enclosed spaces.
- After refueling, replace the gas cap and tighten securely.
- Do not store the product or fuel container, or refuel, where there is an open flame, spark, or pilot light such as on a water heater or other appliance.
- If you spill fuel on your clothing, change clothing immediately.
- If fuel is spilled, do not attempt to start the engine and avoid creating any source of ignition until fuel vapors have dissipated. To help prevent fires: keep product free of grass, leaves, or other debris build up; clean up oil or fuel spillage and remove any fuel soaked debris; allow product to cool before storing.
- Use extra care in handling gasoline and other fuels. They are flammable and vapors are explosive.
- Gasoline and gasoline fumes are poisonous and very flammable. Be careful with gasoline to prevent injury or fire.
- Let the engine become cool before you refuel.
- Do not fill fuel near sparks or naked flames.
- If there are leaks in the fuel system, do not start the engine until the leaks are repaired.
- Do not fill above recommended fuel level. The heat from the engine and the sun makes the fuel expand and the fuel overflows if the tank is filled too much.
- Store the product and fuel in such a way that there is no risk that fuel leaks or fumes can cause damage.

Transport safety

- Do not tow this product.
- Use an approved transport vehicle for transportation of the product.
- A market's national or local regulations can set limit to the transportation of the product.
- The operator of the transport vehicle is responsible to attach the product safely during transport. Refer to Transportation on page 24.

Hauling

Use full width ramps for loading and unloading a product for transport.

Battery safety

- **WARNING:** A damaged battery can cause an explosion and cause injury. If the battery has a deformation or is damaged, speak to an approved Husqvarna service agent.
- **WARNING:** Read the warning instructions that follow before you use the product.
- Use protective glasses when you are near batteries.
- Do not wear watches, jewelry or other metal objects near the battery.
- Keep the battery out of reach for children.
- Charge the battery in a space with good airflow.
- Keep flammable materials at a minimum clearance of 1 m when you charge the battery.
- Discard replaced batteries. See Disposal on page 25.
- Explosive gases can come from the battery. Do not smoke near the battery. Keep the battery away from open flames and sparks.

Safety instructions for maintenance

- **WARNING:** Read the warning instructions that follow before you use the product.
- **WARNING:** The product is heavy and can cause injury or damage to property or the adjacent area. Do not do maintenance on the engine or the cutting deck without these conditions:
 - The engine is off.
 - The product is parked on a level surface.
 - The parking brake is applied.
 - The ignition key in stop position and removed.
 - The blades are disengaged.
 - All moving parts have stopped.
 - The ignition cables are removed from the spark plugs.
- **WARNING:** Fluid escaping under pressure may have sufficient force to penetrate skin and cause serious injury. If fluid is injected into the skin, seek immediate medical attention. Keep body and hands away from pin holes or nozzles that eject fluid under high pressure. If a leak occurs, have the product immediately serviced by a trained technician.
- **WARNING:** The exhaust fumes from the engine contain carbon monoxide, an odorless, poisonous and very dangerous gas. Do not run the product in closed spaces or spaces with no sufficient air flow.
- Keep the product in good working order. Replace worn or damaged parts.
- Use caution when servicing blades. Wrap the blade(s) or wear gloves. Replace damaged blades. Do not repair or alter blade(s).
- If equipped, disconnect spark plug wire(s) and the negative battery cable before making any repairs. For best performance and safety, do maintenance on the product regularly as given in the maintenance schedule. Refer to Maintenance schedule on page 15.
- Electrical shocks can cause injuries. Do not touch the cables when the engine is on. Do not do a function test on the ignition system with your fingers.
- Let the product become cool before you do maintenance near the engine.
- The blades are sharp and can cause cuts. Wind protection around the blades or use protective gloves when

you do work on the blades.

- Do not turn the engine over if the spark plug or ignition cable is removed.
- Make sure that all nuts and bolts are tightened correctly and that the equipment is in good condition.
- Do not change the adjustment of governors.
- If the engine speed is too high, the product components can become damaged. Refer to Technical data on page 26 for highest permitted engine speed.
- The product is approved only with the equipment supplied or recommended by the manufacturer.

Operation

• Introduction

- **WARNING:** Before you operate the product, you must read and understand the safety chapter.

Husqvarna Connect

- Husqvarna Connect is a free app for your mobile device. The Husqvarna Connect app gives extended functions for your Husqvarna product.
- Extended product information.
- Information about, and help with, product parts and servicing.

To start to use Husqvarna Connect

1. Download the Husqvarna Connect app on your mobile device.
2. Add in the Husqvarna Connect app.
3. Follow the instruction steps in the Husqvarna Connect app to connect and add the product.

Note Husqvarna Connect app is not available for download in all markets. Speak to your servicing dealer for more information.

To operate the product for the first time

- **WARNING:** Before you operate the product for the first time, you must read and understand this chapter.
- Use a decreased throttle speed and a decreased ground speed when you operate the product for the first time.
- Do not move the control levers to the fully forward position or the fully reverse position during the initial operation.
- Learn how to operate the movement of the product on a hard surface, for example concrete or asphalt, before you operate the product on a lawn for the first time.
- To do before you operate the product
- **WARNING:** Before you operate the product, you must read and understand the safety chapter.
- **WARNING:** Before you operate the product, you must make sure that there are no stones or other objects in the work area that can be thrown by the rotating blades.
- Do the daily maintenance. Refer to Maintenance schedule on page 15.
- Make sure that there is sufficient fuel in the fuel tank.
- Set the cutting height. Refer to To set the cutting height on page 13.

To fill fuel


- **WARNING:** Gasoline is very flammable. Be careful and refuel outdoors, refer to Fuel safety on page 10.
- **WARNING:** The engine and the exhaust system become very hot during operation. Risk of burn injury. Let the engine and the exhaust system become cool before you fill fuel in the product.
- **WARNING:** Do not use the fuel tank as a support area.
- **CAUTION:** Incorrect type of fuel can result in engine damage.

The engine runs on gasoline with a minimum octane rating of 91 RON (87 AKI), not mixed with oil. We recommend biodegradable alkylate gasoline.


- Do a check of the fuel level before each use and refuel if it is necessary.
- Do not fill the fuel tank fully. Fill to the bottom of the fuel tank neck.

To adjust the seat

- The position of the seat can be moved forward or rearward and the suspension of the seat can be adjusted. The suspension on the left side and right side of the seat are adjusted independently.
- **WARNING:** Do not make adjustments to the seat when the product is in operation.
- To adjust the suspension, do these steps:
 - Pull the handle on the suspension adjuster to release the pin.




- Move the handle in the direction of “-” for softer suspension.
- Move the handle in the direction of “+” for harder suspension.
- Do the same procedure on the suspension adjuster on the opposite side.
- To adjust the position of the seat, push the lever (B) below the seat to the side and push the seat forward or rearward.



To engage and disengage the parking brake

- **CAUTION:** The product must be stationary when you engage the parking brake.
- To engage the parking brake, push the large pedal (A) forward until the latch bracket engages the latch pin.




- To disengage the parking brake, push the small pedal (B) of the latch bracket and let the large pedal (A) and the small pedal (B) move back slowly.

To disengage and engage the drive system

- **CAUTION:** Only disengage or engage the drive system when the product is parked on level ground.
- If it is necessary to move the product by hand, with the engine off, the drive system must be disengaged. The drive system is disengaged and engaged by the bypass valves. The bypass valves are found on the front of each transmission.

Follow the procedure below to disengage the drive system.

1. Park the product on level ground and stop the engine. Do not engage the parking brake.
2. Set the cutting deck to the lowest position.
3. Turn the 2 bypass levers to the horizontal position. There is 1 bypass lever on each side of the product.




4. Push the product by hand.

CAUTION: Do not push the control levers.

5. To engage the drive system, turn the 2 bypass levers to the vertical position.

To set the cutting deck in transport position or mow position
The cutting deck must be in transport position during transportation.


- To set the product in transport position, push the deck lift pedal (A) forward until the cutting deck latches in the transport position.



- To set the product in mow position, push the deck release pedal (B).

To set the cutting height

1. Set the cutting deck in transport position. Refer to To set the cutting deck in transport position or mow position on page 13.
2. Turn the cutting height adjustment knob.




- Turn clockwise to increase the cutting height.
 - Turn counterclockwise to decrease the cutting height.
3. Lower the cutting deck into mow position. Refer to To set the cutting deck in transport position or mow position on page 13.

Cutting height setting	Cutting height, in./cm
1	1.5/3.8

Cutting height setting	Cutting height, in./cm
2	1.75/4.4
3	2.0/5.1
4	2.25/5.7
5	2.5/6.4
6	2.75/7.0
7	3.0/7.6
8	3.25/8.3
9	3.5/8.9
10	3.75/9.5
11	4.0/10.2
12	4.25/10.8
Transport position	4.5/11.4

To start the engine


1. Sit in the seat.
2. Set the cutting deck to the transport position. Refer to To set the cutting deck in transport position or mow position on page 13.
3. Engage the parking brake. Refer to To engage and disengage the parking brake on page 12.
4. Move the throttle control (A) to ½ throttle position.




5. Push and turn the ignition key (B) to the start position.
6. Release the ignition key immediately when the engine starts.
Note: Do not keep the ignition key in the start position for more than 5 seconds at a time. If the engine does not start, wait 15 seconds before you try again.
7. Let the engine run at ½ throttle for 3–5 minutes before you apply full throttle.
8. Push the throttle control to the full throttle position.

To operate the product


1. Start the engine. Refer to To start the engine on page 14.
2. Disengage the parking brake. Refer to To engage and disengage the parking brake on page 12.
3. Carefully push the 2 control levers forward. The product will start to move forward. The forward speed increases the more the 2 control levers are pushed forward.



4. Carefully pull the 2 control levers rearward. The product will start to move rearward. The rearward speed increases the more the 2 control levers are pulled rearward.
5. Put the 2 control levers in neutral position to decrease the speed and stop the product.
6. Do the steps that follow to turn left or right when you go in a forward direction.
 - Pull the left control lever rearward in the direction of the neutral position to make the product turn left. The more you pull the left control lever rearward, the more the product will turn left.



- Pull the right control lever rearward in the direction of the neutral position to make the product turn right. The more you pull the right control lever rearward, the more the product will turn right.



7. Do the steps that follow to make a zero turn.

- Pull the 2 control levers rearward in the direction of the neutral position to decrease the speed or stop the product.
- Move 1 control lever slightly forward and the other control lever slightly rearward to make a zero turn.


8. Lower the cutting deck to mow position. Refer to To set the cutting deck in transport position or mow position on page 13.

9. Pull up the PTO button to engage the drive of the blades.

10. If it is necessary to adjust the cutting height during operation, refer to To set the cutting height on page 13.

To stop the engine


1. Move the 2 control levers to the neutral position to stop the product.
2. Engage the parking brake.
3. Push down the PTO button to disengage the drive of the blades.



4. Put the cutting deck in the transport position.
5. Move the throttle control to the minimum throttle position.
6. Let the engine idle for a minimum of 1 minute until the engine is at usual operation temperature.
7. Turn the ignition key to the stop position.
8. Remove the ignition key from the ignition when you are away from the product.

To get a good cutting result

- For best performance, do maintenance on the product regularly as given in the maintenance schedule. Refer to Maintenance on page 15.
- Do not cut a wet lawn. Wet grass can give a bad cutting result.
- Start with a high cutting height and decrease it gradually.
- Use full throttle when you cut the grass.
- Move the product forward at low speed if the grass is high and thick.
- Cut the grass in an irregular pattern.
- When you cut large areas, move the product to the right during 1 or 2 turns around the work area. This procedure will keep the grass discharge away from shrubs, fences and driveways. After approximately 2 turns around the work area, cut in the opposite direction.



- When the mulch kit is used, cut the grass more frequently.
- To get the best cutting result, cut the grass frequently.

Maintenance

Introduction

- **WARNING:** Before you do any maintenance work you must read and understand the safety chapter.
- Maintenance schedule
- * = The instructions are not given in this operator's manual.

- X = The instructions are given in this operator's manual.
- O = Refer to the engine manual for instructions.

Maintenance schedule for the operator

Maintenance	Daily maintenance		Do maintenance at a minimum of 1 time each year	Maintenance interval in hours		
	Before	After		25	100	500
Do a check of the parking brake.	X		X	X	X	X
Do a check of the engine oil level.	O					
Do a check of the safety system.	X					
Make sure that there are no fuel or oil leaks from the product.	*					
Make sure that there are no damages on the product.		*				
Make sure that there are no loose parts.		*				
Do a check for damages on the cutting deck.		*				
Do a check of the cutting deck for adjustment.			X			X
Do a check of the tire pressure.				X	X	X
Do a check of the battery connections.			X	X	X	X
Do a check of the throttle cable.					O	O
Do a check of the front wheels.			X		X	X
Do a check of the clearance of the engine valve. ¹			*			*
Clean the air intake of the engine. ²			O	O	O	O
Clean the bottom side of the cutting deck.		X				
Clean around the engine.		*				

Clean around the belts and the belt pulleys.		*			*	*
Do a check of the belts and the belt pulleys.			X		X	X
Clean the foam pre-filter (if equipped). ³			O	O	O	O
Maintenance	Daily maintenance		Do maintenance at a minimum of 1 time each year	Maintenance interval in hours		
	Before	After		25	100	500
Replace the foam pre-filter (if equipped). ⁴			O			
Clean the paper filter cartridge. ⁵			O	O	O	O
Examine the muffler and spark arrester screen.			*		*	*
Start the engine and blades and listen for unusual sounds.		*				
Sharpen the blades. ⁶			X	X	X	X
Replace the blades.			X	X	X	X
Replace the spark plugs.			O		O	O
Replace the engine oil. ⁷			O		O	O
Replace the engine oil filter.			O		O	O
Replace the fuel filter.			O		O	O
Replace the paper air filter. ⁸			O		O	O

To clean the product

- **CAUTION:** Do not use a high-pressure washer or a steam cleaner. Water can go into bearings and electrical connections and cause corrosion which causes damage to the product.
- Clean the product immediately after use.
- Do not clean hot surfaces such as the engine, muffler and exhaust system. Wait until the surfaces are cool, then remove the grass or dirt.
- Before you clean with water, clean with a brush. Remove grass and dirt on and around the transmission, the transmission air intake, and the engine.
- Use running water from a hose to clean the product. Do not use high-pressure.
- Do not point the water at electrical components or bearings. Detergent usually increases the damage.
- Use compressed air to clean the top side of the mower deck.
- Use a water hose to clean below the cutting deck.
- When the product is clean, start the cutting deck for a short period to remove remaining water.

To clean the engine and the muffler

- Keep the engine and muffler free from grass cuttings and dirt. Grass cuttings soaked in fuel or oil on the engine can increase the fire risk and the risk that the engine becomes too hot. Let the engine cool before it is cleaned. Clean with water and a brush.
- Grass cuttings around the muffler dry quickly and are a fire risk. Use a brush or remove the grass cuttings with water when the muffler is cold.

To clean the battery

Corrosion and dirt on the battery and the terminals can cause the power of the battery to decrease.

1. Remove the battery. Refer to To remove and install the battery on page 18.
2. Flush the battery with water and let dry.
3. In conditions with dust, cleaning and replacement must be done more frequently.
4. In conditions with dust, cleaning and replacement must be done more frequently.
5. Must be done by approved service agent.
6. Replace the engine oil after the first 8-10 hours of operation. During heavy load or high ambient temperatures, replace the engine oil each 50 hours.
7. In conditions with dust, cleaning and replacement must be done more frequently.

CAUTION: Do not use a high-pressure washer or a steam cleaner. Water can go into bearings and electrical connections and cause corrosion which causes damage to the product.
8. Clean the terminals and the cable ends of the battery cables with a wire brush.

To do a check of the parking brake

1. Park the product on a slope with a hard surface.

Note: Do not park the product on a grass slope when you do a check of the parking brake.
2. Engage the parking brake.
3. If the product starts to move with the parking brake engaged, let an approved service agent adjust the parking brake.
4. Disengage the parking brake.

To charge the battery

- Charge the battery if it is too weak to start the engine. Refer to Battery charging times on page 28 for battery charging times.
- Use a standard battery charger.


CAUTION: Do not use a boost charger or start booster. A boost charger or a start booster will cause damage to the electrical system of the product.

- Always disconnect the battery charger before you start the engine.
- **To do an emergency start of the engine**
 - If the battery is too weak to start the engine, you can use jumper cables to do an emergency start. This product has a 12 V system with negative ground. The product that is used for the emergency start must also have a 12 V system with negative ground.
 - To connect the jumper cables

- **WARNING:** Risk of explosion because of explosive gas that comes from the battery. Do not connect the negative terminal of the fully charged battery to or near the negative terminal of the weak battery.

CAUTION: Do not use the battery of the product to start other vehicles.

1. Connect one end of the red cable to the POSITIVE battery terminal (+) on the weak battery (A).



2. Connect the other end of the red cable to the POSITIVE battery terminal (+) on the fully charged battery (B).
WARNING: Do not short circuit the ends of the red cable against the chassis.
3. Connect one end of the black cable to the NEGATIVE battery terminal (-) on the fully charged battery (C).
4. Connect the other end of the black cable to a CHASSIS GROUND (D), away from the fuel tank and the battery.


To remove the jumper cables

Note: Remove the jumper cables in the opposite sequence to how you connect them.

1. Remove the BLACK cable from the chassis.
2. Remove the BLACK cable from the fully charged battery.
3. Remove the RED cable from the 2 batteries.

To remove and install the battery

1. Remove the battery compartment cover below the seat.
2. Remove the 2 screws (A) from the battery bracket (B) and remove the battery bracket.



3. Use a wrench to disconnect the black battery cable from the negative (-) terminal on the battery.
4. Use a wrench to disconnect the red battery cable from the positive (+) terminal on the battery.
5. Carefully remove the battery from the product.
6. Install in the opposite sequence.

To adjust the tracking speed

If the product does not move straight forward, the tracking speed must be adjusted.

WARNING: Always adjust the tracking speed in an open area without bystanders.


1. Do a check of the tire pressure. Refer to Tire pressure on page 19.
2. Turn the tracking controls fully in. Refer to Tire pressure on page 19 for the location of the tracking controls.
3. Turn the tracking controls out 4 turns.
CAUTION: More than 4 turns can cause damage to the product.
4. Start the product.
5. Move the control levers forward fully and operate the product at full throttle.
6. Turn the tracking control on the right side gradually until the product starts to move right.
7. Turn the tracking control on the left side gradually until the product starts to move straight forward.

Tire pressure

Make sure that the tire pressure is correct in all 4 tires. Refer to Technical data on page 26.

To remove and install the front wheels

1. Remove the nut and the bolt to remove the front wheels from the forks. It is not necessary to remove the tube (A).



2. Install in the opposite sequence. Torque the nut and bolt to 60–85 ft-lbs / 81–115 Nm.


CAUTION: Make sure that the tube (A) is installed correctly. If the tube is not installed, the performance will be bad and the life of the wheel is decreased.

To adjust the anti-scalp rollers

The anti-scalp rollers keep the cutting deck in the correct position on the ground and prevent lawn scalping in most terrain conditions. The anti-scalp rollers can be set in 3 positions for different lengths of grass:

- **Top position:** 1.5–2.5 in. / 38–64 mm grass.
- **Middle position:** 2.5–4 in. / 64–102 mm grass.
- **Bottom position:** 4–5 in. / 102–127 mm grass.

1. Park the product on level ground and stop the engine.
2. Remove the nut, the bolt, the axle and the anti-scalp roller.




3. Install the anti-scalp roller in one of the 3 positions.

CAUTION: The cutting deck can become damaged if the anti-scalp rollers are incorrectly adjusted. The anti-scalp rollers must be approximately 1/4 in. / 6.4 mm from the ground.

To adjust the parallelism of the cutting deck


This procedure will set the cutting deck in a standard position.

1. Make sure that the tire pressure is correct. Refer to Tire pressure on page 19.
2. Park the product on a level surface.
3. Turn the outer blade tips to align with the cutting deck side to side.




WARNING: The blades on the cutting deck are sharp and can cause injury. Use protective gloves.

4. Measure the distance between the ground and the bottom of the blade tip on the discharge side of the cutting deck. Make a note of the distance.
5. Measure the distance between the ground and the bottom of the blade tip on the side opposite to the discharge side. The distance must be the same as the distance for the discharge side. If adjustment is necessary, adjust the locknut on the top of the rear links until the 2 side to side distances are equal.



6. Turn the 2 outer blades to align with the cutting deck front to rear.



7. Adjust the 2 front bolts until the rear blade tips are set 1/8–3/8 in. / 3.2-9.5 mm higher in the rear than in the front blade tips.
8. Measure the distances again to make sure that the cutting deck has been adjusted correctly.

To examine the blades

CAUTION: Damaged or incorrectly balanced blades can cause damage to the product. Replace damaged blades. Let an approved service agent help you sharpen and balance blunt blades. Look at the blades to see if they are damaged and if it is necessary to sharpen them.

To replace the blades

1. Remove the blade bolt.
2. Assemble the new blade with the side without stamps in the direction of the cutting deck.


WARNING: Incorrect blade type can cause objects to eject from the cutting deck and cause serious injury. Use only approved blades.

3. Attach the blade bolt. Torque the bolt to 61–75 Nm.

To remove the deck belt

Park the product on level ground and engage the parking brake before you do this task.

1. Set the cutting deck in the lowest position.
2. Remove the 2 belt covers.
3. Remove dirt and unwanted materials from around the cutter housings and the cutting deck surface.
4. Push in the idler arm to decrease the tension on the deck belt and carefully remove the deck belt from the pulleys



5. Remove the deck belt from the electric clutch on the engine shaft.


To install the deck belt

1. Put the deck belt around the electric clutch pulley on the engine shaft.
2. Put the deck belt around the pulleys on the cutting deck.
Note: Refer to the routing decal on the cutting deck when you install the deck belt.
3. Push in the idler arm until you can put the deck belt around the stationary idler pulley and hold it there.
4. Carefully put the deck belt around the stationary idler pulley and slowly release the idler arm back into position.
5. Make sure that the belt routing align with the belt routing shown on the belt routing decal.
6. Make sure that the deck belt is not twisted.
7. Install the 2 belt covers.

To remove the pump belt

Park the product on level ground and engage the parking brake before you do this task.

1. Lift the rear of the product and put supports below it.
2. Remove the drive wheels.
3. Remove the deck belt. Refer to To remove the deck belt on page 20.
4. Remove the clutch stop to get access to the pump belt.
5. Loosen the nuts on the eye bolt to decrease the tension in the pump belt.
- 6.




Remove the pump belt from the engine and the pump pulleys.

To install the pump belt

1. Loosen the nuts on the eye bolt to decrease the tension in the pump belt.
2. Put the pump belt around the right and left pump pulleys.
3. Put the pump belt around the engine pulley.
4. Install the clutch stop
5. Turn the nut on the eye bolt on the idler pulley to adjust the tension of the pump belt. The length of the spring must be 1.38–1.50 in
6. Install the deck belt. Refer to To install the deck belt on page 21
7. Install the drive wheels
8. Remove the supports and lower the rear of the product.

To do a check of the engine oil level

1. Park the product on level ground and stop the engine.
2. Loosen the dipstick and pull it out.
3. Clean the oil from the dipstick.
4. Put the dipstick in the hole for the dipstick and tighten it.
5. Loosen and pull the dipstick out and read the oil level.
6. The oil level must be between the marks on the dipstick. If the level is near the ADD mark, fill oil to the FULL mark.



7. Fill the oil through the hole for the dipstick. Fill the oil slowly.

Note: Refer to Technical data on page 26 for the types of engine oil that Husqvarna recommends. Do not mix different types of oil.

8. Tighten the dipstick fully before you start the engine.

To replace the engine oil

If the engine is cold, start the engine for 1–2 minutes before you drain the engine oil. This makes the engine oil warm and faster to drain.

- **WARNING:** Do not operate the engine for more than 1–2 minutes before you drain the engine oil. The engine oil becomes very hot and can cause burn injuries. Let the engine become cool before you drain the engine oil.
- **WARNING:** If you spill engine oil on your body, clean with soap and water.

1. Park the product on level ground and stop the engine.
2. Engage the parking brake. Refer to To engage and disengage the parking brake on page 12.
3. Remove all dirt around the oil tank cap.
4. Remove the oil tank cap and the dipstick.
5. Find the oil drain plug on the engine. Refer to Product overview on page 3.
6. Put a container below the oil drain plug.
7. Remove the oil drain plug.
8. Let the oil run out into the container.
9. Replace and install the oil drain plug.
10. Fill with new oil and do a check of the engine oil level. Refer to To do a check of the engine oil level on page 21.
11. Install the oil tank cap and the dipstick.

Note: For safe disposal of used engine oil, refer to Disposal on page 25.

Lubrication, general information

- Remove the ignition key to prevent accidental movements during lubrication.
- Clean the area before you lubricate a part on the product.
- Use oil when you lubricate with an oil can. When you lubricate with grease, use a chassis or ball bearing grease that prevents corrosion. Remove unwanted grease after lubrication.
- Lubricate 2 times a week if you operate the product daily.
- Do not spill lubricant on the drive belts or the grooves of the belt pulleys. If you do spill, clean with alcohol.
- If the friction between the drive belt and the pulley is not sufficient after you clean with alcohol, replace the drive belt.

CAUTION: Do not use gasoline or other petroleum products to clean drive belts.

Troubleshooting

Troubleshooting schedule

If you cannot find a solution to your problems in this operator's manual, speak to your Husqvarna service agent.

Problem	Cause
The engine does not start.	The drive of the blades is engaged. Refer to PTO (Power Take- Off) button on page 5.
	Steering controls are not locked in the neutral position.
	The battery is too weak. Refer to To charge the battery on page 18.
	There is dirt in the carburetor or fuel line.
	The fuel filter or fuel line is clogged.
	The ignition system is damaged.

Problem	Cause
The starter motor does not turn the engine over.	The battery is too weak. Refer to To charge the battery on page 18.
	The connection at the cable connectors on the battery terminals is bad. Refer to To clean the battery on page 17.
	A fuse is blown. Refer to Fuses on page 6.
	The OPC is damaged. Refer to Operator Presence Control (OPC) on page 5.
The engine does not run smoothly.	The carburetor is incorrectly set.
	The fuel filter or fuel jet is clogged.
	The check valve on the fuel tank cap is clogged.
	The fuel tank is almost empty.
	The spark plug is damaged.
	Incorrect fuel mix or fuel type.
	There is water in the fuel.
	The air filter is clogged.
The engine apparently has no power.	The air filter is clogged.
	The spark plug is damaged.
	The carburetor is incorrectly set.

	There is air in the hydraulic system.
There is vibration in the product.	The blades are loose. Refer to To examine the blades on page 20 .
	One or more of the blades are not balanced. Refer to To examine the blades on page 20 .
	The engine is loose.
The engine becomes too hot.	The air filter or the cooling fins are clogged.
	There is overload in the engine.
	The airflow around the engine is not sufficient.
	The engine speed regulator is damaged.
	The oil level is too low.
	There is dirt in the fuel line.
	The spark plug is damaged.
The battery does not charge.	The connection at the cable connectors on the battery terminals is bad. Refer to To clean the battery on page 17 .
	The charging cable is disconnected.
	The charging system is damaged.
The product moves slowly, with irregular speed or not at all.	The bypass linkages are engaged.
	The drive belt on the transmission is loose or damaged.
	There is air in the hydraulic system.

Problem	Cause
The drive of the blades do not engage.	The drive belt on the mower deck is loose.
	The electromagnetic coupling contact is loose.
	The drive of the blade is damaged or loose from the cable connectors.
	A fuse is blown.
The transaxle leaks oil.	The seals, housing or gaskets are damaged.
	There is air in the hydraulic system.
The cutting result is unsatisfactory.	The tire pressure is different on the right and left sides. Refer to Tire pressure on page 19 .
	The blades are damaged.
	The suspension of the cutting deck is not level.
	The blades are blunt. Refer to To examine the blades on page 20 .
	The product is operated at too high forward or rearward speed. Refer to To get a good cutting result on page 15 .
	The grass is long. Refer to Symbols on the product on page 3 .
There is grass blockage in the cutting deck. Refer to To clean the product on page 17 .	

Transportation, storage and disposal

Transportation

- Do not tow the product.
- The product is heavy and can cause crush injuries. Be careful when you load it onto or off a vehicle or trailer.
- Load the product in reverse on approved ramps of a maximum operation angle of 10°. Do not lift the product.
- Use an approved trailer for transportation of the product.
- Make sure that you have knowledge of local road traffic regulations before transportation of the product in a trailer or on roads.
- Lock the product with approved devices, such as straps. Use tie-down points on the product or applicable areas of the frame. The parking brake is not sufficient to lock the product during transportation.

Storage

- Prepare the product for storage at the end of the season, and before more than 30 days of storage. If you keep fuel in the fuel tank for 30 days or more, tacky particles can cause blockage in the carburetor. This has a negative effect on the engine function.
- To prevent tacky particles during storage, add a stabilizer. If alkylate gasoline is used, stabilizer is not necessary. If you use standard gasoline, do not change to alkylate gasoline. This can cause sensitive rubber parts to become hard. Add stabilizer to the fuel in the tank or in the container used for storage. Always use the

mixing ratios given by the manufacturer. Add the stabilizer and run the engine for a minimum of 10 minutes, until the fuel flows into the carburetor.

- **WARNING:** Do not keep the product with fuel in the tank in an indoor location or in locations with bad airflow. Risk of fire if fuel fumes come near open flames, sparks, or pilot lights in for example boilers, hot water tanks and clothes dryers.
- **WARNING:** Remove grass, leaves and other flammable materials from the product to decrease the risk of fire. Let the product become cool before you put it in storage.
 - Clean the product, refer to To clean the product on page 17.
 - Remove unwanted materials from the cooling fan.
 - Repair paint damages to prevent corrosion.
 - Examine the product for worn or damaged parts and tighten loose screws and nuts.
 - Remove the battery. Clean it, charge it, and keep it cool during storage.
 - Replace the engine oil, and discard the waste oil.
 - Empty the fuel tank. Start the engine and run it until there is no remaining fuel in the carburetor.
- **Note:** Do not empty the fuel tank and carburetor if a stabilizer has been added.
 - Remove the plugs and put about a tablespoon of engine oil into each cylinder. Manually turn the engine shaft to apply the oil and put the plugs back on.
 - Lubricate all grease nipples, joints and axles.
 - Keep the product in a clean and dry area and put a cover on it for more protection.

Disposal

- Chemicals can be dangerous and must not be discarded on the ground. Always discard used chemicals at a service center or an applicable disposal location.
- When the product is worn out, send it to the dealer or to an applicable recycling location.
- Oil, oil filters, fuel and the battery can have negative effects on the environment. Obey the local recycling requirements and applicable regulations.
- Do not discard the battery as domestic waste.
- Send the battery to a Husqvarna service agent or discard it at a disposal location for used batteries.

Technical data

Xcite™ Z375		
	54 in./137 cm cutting deck version	60 in./152 cm cutting deck version
Engine		
Brand/model	Kohler/KT745	Kohler/KT745
Nominal engine output, hp/kW ⁹	26/19.4	26/19.4
Displacement, cm ³	747	747
Max. engine speed, rpm	3600 ± 75	3600 ± 75
Fuel, min. octane grade lead-free, max 10% Ethanol, max 15% MTBE	87 AKI/91 RON	87 AKI/91 RON
Tank volume, gal/l	4.31/16.3	4.31/16.3
Oil	<ul style="list-style-type: none"> • Class SF, SG, SH, SJ or • SL SAE40, SAE30, SAE20W-50, SAE10W-40, SAE10W-30, SAE5W-20 	<ul style="list-style-type: none"> • Class SF, SG, SH, SJ or • SL SAE40, SAE30, SAE20W-50, SAE10W-40, SAE10W-30, SAE5W-20
Oil volume, incl. filter, oz/l	66.6/2	66.6/2
Oil volume, excl. filter, oz/l	64/1.9	64/1.9
Lubrication system	Pressure with oil filter	Pressure with oil filter
Cooling system	Air cooled	Air cooled
Air filter	Heavy duty canister	Heavy duty canister
Alternator, V. amp. @ 3600 rpm	12 V 15 amp @ 3500 ± 100 rpm	12 V 15 amp @ 3500 ± 100 rpm
Start motor	Electric start 12 V	Electric start 12 V
Dimensions		
Length, in./cm	78.75/200.3	78.75/200.3
Width, in./cm	49.5/126	49.5/126
Width including chute up, in./cm	54/137	60/152
Width including chute down, in./cm	68/172.7	74/188
Height, in./cm	46/116.8	46/116.8
Weight, with no fuel, lb/kg	794/360.2	873/396
Max. gross vehicle weight rating (GVWR), lb/kg 10	1300/589.6	1300/589.6
Max. gradient, degrees °	10	10

1. The power rating as declared by the engine manufacturer is the average gross power output at the specified RPM of a typical production engine for the engine model measured using SAE Standards for engine gross power. Refer to the engine manufacturer engine specifications.

2. The Max. gross vehicle weight rating (GVWR) is the maximum weight capacity of a fully loaded product. This includes the operator, all accessories, options, equipment, and cargo.

Xcite™ Z375		
Cutting width, in./cm	54/137	60/152
Cutting height, in./cm	1.5-4.5/3.9-11.4	1.5-4.5/3.9-11.4
Cutting deck		
Deck construction	10 gauge fabricated	10 gauge fabricated
Number of blades	3	3
Blade length, in./cm	18.3/46.5	21/53
Blade engagement	Ogura Clutch	Ogura Clutch
Productivity, acres/h / m2/h	3.48/14083	4.35/17603
Tires		
Tire pressure, front, kPa/PSI/bar	103/15/1	103/15/1
Tire pressure, rear, kPa/PSI/bar	103/15/1	103/15/1
Front tires, in.	13 x 6.5-6	13 x 6.5-6
Rear tires, turf pneumatic, in.	22 x 11-10	22 x 11-10
Anti-scalp roller	4 adjustable	4 adjustable
Transmission		
Transmission	Parker HTE10	Parker HTE10
Transmission oil	Parker HT-1000, Castrol Syntec 5W-50, Amsoil AW ISO 68, Shell TTF-SB, or other premium synthetic oil (15W40 min.)	Parker HT-1000, Castrol Syntec 5W-50, Amsoil AW ISO 68, Shell TTF-SB, or other premium synthetic oil (15W40 min.)
Steering control	Dual levers, foam gripped	Dual levers, foam gripped
Maximum speed forward, mph / km/h	9/14.48	9/14.48
Maximum speed reverse, mph / km/h	4.5/7.24	4.5/7.24
Brakes	Mechanical parking brake	Mechanical parking brake
Electrical system		
Battery	12 V 230 CCA Class	12 V 230 CCA Class
Spark plug	XC12YC	XC12YC
Electrode gap, in./mm	0.03/0.76	0.03/0.76
Spark plug torque, ft-lb/Nm	22/27	22/27


Battery charging times

STD battery	State of charge	Approximate charging time to full charge at 80° F / 26° C 11			
		Maximum rate at:			
		50 Amps	30 Amps	20 Amps	10 Amps
12.6 V	100%	Fully charged			
12.4 V	75%	20 min	35 min	48 min	90 min
12.2 V	50%	45 min	75 min	95 min	180 min
12.0 V	25%	65 min	115 min	145 min	280 min
11.8 V	0%	85 min	150 min	195 min	370 min


Service

- Do a yearly check at an authorized service center to make sure that the product functions safely and at its best during high season. The best time to do a servicing or overhaul of the product is low season.
- When you send an order for the spare parts, give information about the purchase year, model, type, and serial number.
- Always use original spare parts.

Electrical diagram




SUGGESTED GUIDE FOR SIGHTING SLOPES FOR SAFE OPERATION



1. . Fold this page along dotted line indicated above.
2. Hold page before you so that its left edge is vertically parallel to a tree trunk or other upright structure.
3. Sight across the fold in the direction of hill slope you want to measure.
4. Compare the angle of the fold with the slope of the hill.

WARNING: To avoid serious injury, operate your unit up and down the face of slopes, never across the face. Do not mow slopes greater than 10 degrees. Make turns gradually to prevent tipping or loss of control. Exercise extreme caution when changing direction on slopes. Do not mow near drop-offs, ditches, or embankments. Keep at least the width of the machine away from these hazards. Failure to follow these warnings could lead to death or serious injury.

- www.husqvarna.com
- Original instructions
-



Documents / Resources

	<p>Husqvarna Xcite Z375 Zero Turn Lawn Mower [pdf] User Manual Xcite Z375 Zero Turn Lawn Mower, Xcite Z375, Zero Turn Lawn Mower, Lawn Mower</p>
---	--

References

- [Husqvarna Forest & Garden](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.