



Configurazioni. Configurations.

Macchina Base Standard Crane


100024 SP




100026 SP



100028 SP




100029 SP




Con Antenna With Jib

100026 SP + J2414.25




100026 SP + J2416.25



Configurazioni. Configurations.

Con Antenna With Jib

100028 SP + J1614.25



100028 SP + J1616.25

